

Important Tips for Operating Your ALX2 Grill

1. Be sure gas supply is turned on
2. Be sure grill is plugged into electrical outlet
3. "Always" be sure grill lid is open when lighting
4. Be sure GFCI outlet doesn't need to be reset?
5. Preheat with grill burners on high and lid closed for 15 minutes. Infrared SearZone and rear rotisserie burners only require 5 minutes preheating time.
6. Infrared Burner Tiles:
Never allow ceramic burner tiles to come in contact with water or liquids. Drippings from food are OK once burner has been fully preheated.
7. When Rotissing:
Always use provided porcelain drip tray to catch drippings.
8. Always keep lid closed when grill isn't in use
9. Always keep provided vinyl cover on grill when not in use.

If Your Grill Fails to Light

1. Is the gas supply turned on?
2. Is grill plugged into electrical outlet?
3. Do you hear spark when igniter button is pressed?
4. Does GFCI outlet need to be reset?
5. Has circuit breaker tripped?
6. Did you bleed gas lines for 20 seconds on initial start-up?

Consult the complete Care & Use manual for more info.

Questions? Visit www.alfrescogrills.com
or call (888) 383-8800 or (323) 722-7900

Alfresco